




Active Height Control Suspension and Electric Modulated Air Suspension




Electric Modulated Air Suspension



Active Height Control Suspension and



Electric Modulated Air Suspension



Active Height Control Suspension and

System Outline

- * The electric modulated suspension with height control, is a system designed to maintain a constant ride height by means of an electro–pneumatic system in the rear suspension – to cope with change in load due to possible change in the number of people and/or the weight of cargo the vehicle has to carry. With three driver’s–choice height–control switches on the console, the driver can set ride height to any one of the three different ride height modes (High, normal and low): "High mode" for rough terrain and "Low mode" for passenger to get on or get off, and for cargo to be loaded or unloaded.
- * This system has five basic controls as shown below:
 - * Auto leveling control
This control maintains a constant rear vehicle ride height regardless of change in load due to possible change in the number of passengers and/or the weight of cargo the vehicle has to carry.
 - * Ride height switchover control
This control switches over height mode to the mode selected by the height control switch.
 - * High mode (+ 40 mm / 1.6 in.)
 - * Low mode (– 20 mm / 0.8 in.)
 - * Speed sensing control
Regardless of the initial height mode setting, "High mode" or "Low mode," this control automatically switches over vehicle height mode to the optimum "Normal mode":
 - * When the vehicle speed reaches or exceeds 30 km/h with height mode set to "High mode," or;
 - * When the vehicle speed reaches or exceeds 5 km/h with height mode set to "Low mode."
 - * Subsequent control after ignition switch off
After the ignition switch is turned OFF, this control lowers the rear vehicle ride height to offset rear vehicle ride height elevation due to passengers getting off, etc.
 - * Height control OFF control
Pressing the absorber control switch turns the system OFF, making it possible for the vehicle to be jacked up or towed.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A23	36	H13	40	J18	A 38
B5	36	H14	40	J19	B 38
C8	A 37	H15	40	J24	38
C9	B 37	H16	40	J31	A 38
C10	C 37	H17	40	J32	B 38
D1	37	J1	33 (2UZ–FE)	L1	40
D12	40	J2	A 33 (2UZ–FE)	S8	39
D13	40	J3	B 33 (2UZ–FE)	S12	39
D14	40	J4	38	S13	A 39
D15	40	J7	38	S14	B 39
E8	37	J8	A 38	S15	C 39
H12	37	J9	B 38		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
2	22	Engine Room R/B (Engine Compartment Left)
4	23	Engine Room R/B No.4 (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	24	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
1G	25	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

Electric Modulated Air Suspension

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	48	Floor No.2 Wire and Engine Room Main Wire (Left Kick Panel)
IB2		
IC2	48	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IC4		
IE1	50	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
IM1	52	Engine Wire and Instrument Panel Wire (Right Side of Blower Unit)
IO1	52	Instrument Panel Wire and Floor Wire (Right Kick Panel)
BC1	54	Frame Wire and Floor No.2 Wire (Under the Rear LH Seat)
BC2		

: Ground Points

Code	See Page	Ground Points Location
EB	44 (2UZ-FE)	Front Left Fender
EF	44 (2UZ-FE)	Rear Side of Left Bank Cylinder Block
II	48	Instrument Panel Brace RH
BN	54	Near the No.5 Crossmember of Side Frame LH

: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B5	54	Frame Wire			